


Venturimeter

It is a device based on Bernoulli's theorem used for measuring the rate of flow of liquid through pipes.

It consists of two identical coaxial tubes *A* and *C* connected by a narrow coaxial tube *B*. Two vertical tubes *D* and *E* are mounted on the tubes *A* and *B* to measure the pressure of the flowing liquid.



When the liquid flows in the tube *ABC*, the velocity of flow in part *B* will be larger than in the tube *A* or *C*. So the pressure in part *B* will be less than that in tube *A* or *C*. By measuring the pressure difference between *A* and *B*, the rate of flow of the liquid in the tube can be calculated.

Let a_1 and a_2 are area of cross section of tube *A* and *B* respectively

v_1, v_2 = Velocity of flow of liquid through *A* and *B* respectively

P_1, P_2 = Liquid pressure at *A* and *B* respectively

$$\therefore P_1 - P_2 = h\rho g \quad \dots(i) \quad [\rho = \text{density of flowing liquid}]$$

From Bernoulli's theorem for horizontal flow of liquid

$$P_1 + \frac{1}{2} \rho v_1^2 = P_2 + \frac{1}{2} \rho v_2^2$$

$$P_1 - P_2 = \frac{1}{2} \rho (v_2^2 - v_1^2) \quad \dots(ii)$$

$$\text{From (i) and (ii) } h\rho g = \frac{1}{2} \rho (v_2^2 - v_1^2) = \frac{1}{2} \rho \left[\frac{V^2}{a_2^2} - \frac{V^2}{a_1^2} \right] \quad [\text{As } V = a_1 v_1 = a_2 v_2]$$

$$\therefore V^2 = \frac{2a_1^2 a_2^2 h g}{a_1^2 - a_2^2} \quad \text{or} \quad V = a_1 a_2 \sqrt{\frac{2hg}{a_1^2 - a_2^2}}$$