


---

### Colour of hydrated transition metal ions and their compounds :

- A substance is coloured, if it absorbs a part of white light and transmit the remaining light.
- The colour of a substance is the complementary colour of that part of visible light which is absorbed by the substance.
- Colour is due to the presence of partly filled d-orbitals, with unpaired electrons.
- The metal ion possessing completely filled d-orbitals or completely vacant d-orbitals is colourless. Ex  $\text{TiO}_2$ ,  $\text{CuCl}$ .
- d-orbitals are degenerate in isolated gaseous metal ions.
- d-orbitals of the metal ion in compounds or hydrated ions or complexes possess slightly different energies.
- Under the influence of the anion of the compound or the water molecule in hydrated state these d-orbitals of the metal ions split into 2 sets. It is known as d-orbital splitting.
- One set consists of two orbitals -  $d_{x^2-y^2}$ ,  $d_{z^2}$  of higher energy and the other set consists three orbitals -  $d_{xy}$ ,  $d_{yz}$ ,  $d_{zx}$  of lower energy.



- Electron in the lower energy d-orbital is promoted to higher energy d-orbital within the same energy level.
  - Thus, the colour of transition metal ions involves d-d transitions.
  - This excitation is possible in the visible region ( $\lambda = 400 - 750 \text{ nm}$ ) as the energy difference between the two sets is less.
  - $[\text{Ti}(\text{H}_2\text{O})_6]^{3+}$  absorbs green and yellow lights and transmits pink colour.
  - The same metal ion may exhibit different colours in different oxidation states.
  - $\text{Fe}^{2+}$  - green ;  $\text{Fe}^{3+}$  - yellow
  - $\text{Cr}^{2+}$  - blue  $\text{Cr}^{3+}$  - green  $\text{Cr}^{6+}$  - yellow
  - $\text{Mn}^{2+}$  - pink  $\text{Mn}^{3+}$  - blue  $\text{Mn}^{6+}$  - green
  - $\text{Sc}^{3+}$ ,  $\text{Ti}^{4+}$ ,  $\text{Mn}^{7+}$  - are colourless as all the d-orbitals in these ions are vacant
  - $\text{Cr}^{6+}$  and  $\text{Mn}^{7+}$  possess vacant d orbitals but their oxyanions like  $\text{Cr}_2\text{O}_7^{2-}$ ,  $\text{CrO}_4^{2-}$  and  $\text{MnO}_4^-$  are coloured due to charge transfer phenomenon.
  - $\text{Zn}^{2+}$  and  $\text{Cu}^+$  are colourless as all the d orbitals are completely filled.
-

---

### Alloys:

- Homogenous mixture of a metal with other metal or metalloid or non metal having metallic properties is known as an alloy.
- Transition metals form alloys easily because they have similar atomic radii and similar crystal structures.
- Alloys are prepared to modify certain properties like malleability, ductility, toughness, resistance to corrosion to suit the needs in the industry.
- Alloys are classified as  
Ferrous alloys (contain iron) Ex. Cast Iron. Stainless steel,  
Non Ferrous alloys (no iron ) ex. Brass, German silver.
- Alloys are prepared, by mixing the metals or components in proper composition in molten state and solidifying.
- By simultaneous electrolytic deposition of metals under the same conditions to get alloys.

Alloy	Composition	Uses
Invar	64% Fe, 35% Ni. Mn and C in trace amounts.	To make pendulum rods, due to low temperature coefficient
Nichrome	60% Ni, 25% Fe 15% Cr.	To manufacture heating elements of stoves and Furnaces
<b>Non – Ferrous alloys</b>		
Type metal	60–80 % Pb, 13–30% Sb, 3–10% Sn.	Used for sharply defined castings
Wood’s metal	50% Bi, 25% Pb, 12.5% Sn, 12.5% Cd,	In automatic alarms. Sprinklers systems
Devarda’s Alloy	50% Cu, 45% Al, 5% Zn	To reduce nitrites and nitrates to $\text{NH}_3$
Solder metal	50% Sn, 47.5% Pb, 2.5 % Sb	Electrical appliances
Duralumin	95% Al, 4% Cu, 0.5% Mn, 0.5 %Mg.	Aircraft
Magnalium	85-99% Al, 1–15% Mg	Balance beams, aircraft parts, motor spares
Aluminium Bronze	88–90% Cu, 10–12% Al	Ornaments, Photoframes, coins
German silver	50–60% Cu, 10–30 % Ni, 20–30% Zn	Spoons, forks, Utencils
Bell metal	80% Cu, 20% Sn	Bells
Bronze	75 – 90% Cu, 10 –25% Sn	Utensils, Coins and statues

---

---

Gun metal	88% Cu, 10% Sn, 2% Zn	Bearings, guns
Brass	60–80% Cu, 20–40 % Zn	Machine parts
<b>STEELS :</b>		
<b>Name of the steel</b>	<b>% of the element present</b>	<b>Uses</b>
Nickel steel	2.5 – 5 % Ni, Fe, C	Cable wires, guns
Manganese steel	10– 14% Mn, Fe, C	Ball mills, Helmets
Chromium steel	5 – 15% Cr, Fe, C	Kitchen ware, Razorblades
Tungsten steel	6–8% W; 14–20% Fe, C	Magnets, Electric motors

Alloys are used in nuclear engineering, dental fillings, to manufacture magnetic materials.

---